

DefendEar®

**DIGITAL**

**CABLE  
USER GUIDE**



# SETUP

Press module end into earpieces until they snap into place.



# TECHNICAL INFORMATION

**Impedance:** 32 ohms

**Sensitivity:** 106dB

**Weight:** 10g (earphone model)

**Color:** Black

# BLUETOOTH HEADSET

Charging Port



Call Button

Call Functions

Music

**Answer / End Call**  
Short Press

**Ignore Call**  
Long Press

**Redial**  
Double Press

**Play/Pause**  
Short Press

## **CONNECTING THE BLUETOOTH:**

1. With the power off, press and hold the answer button until the headset enters pairing mode. This will be indicated by the LED indicator alternating flashing of red & blue.
2. Open the Bluetooth® function on your mobile device and search for Bluetooth® devices, the headset will show up with the name “BT”.
3. When in pairing mode, double tap the call button to toggle between the two language options English and Chinese.
4. Click the device name and select “connect to this device”. When successfully connected the LED indicator will be flashing blue.

**NOTE:** On some devices, you may be prompted to enter a password during the Bluetooth® connection process, this will be “0000”.

**NOTE:** To connect a second mobile device repeat steps 1-3.

# SMARTPHONE HEADSET

Volume + - Slider

Multi-Function Button



Microphone

## **Multi-Function Button:**

### **iPhone:**

#### **Playing Music**

Single Press: Play/Pause

Double Press: Skip Track

#### **Phone Calls**

Single Press: Answer/End Call

#### **General**

Long Press: Launch Siri

### **Android:**

#### **Playing Music**

Single Press: Play/Pause

Double Press: Skip Track

#### **Phone Calls**

Single Press: Answer/End Call

#### **General**

Long Press: Launch Google Assist

# **Westone**<sup>®</sup>

THE IN-EAR EXPERTS<sup>®</sup>

**Phone:** 719-540-9333 | **Toll Free:** 800-525-5071  
2235 Executive Circle | Colorado Springs, CO 80906

**[www.westone.com/defendear](http://www.westone.com/defendear)**

© 2019 Westone<sup>®</sup> Laboratories, Inc. All rights reserved.

PN 99714 Rev1