

## OTHER WESTONE PRODUCTS



**W SERIES**



**UM PRO SERIES**



**ADVENTURE SERIES**



**ELITE SERIES**

# Westone<sup>®</sup>

2235 Executive Circle, Colorado Springs, CO 80906  
westoneaudio.com | 800.525.5071 | PN 98300 | rev 1

# INSERTION & REMOVAL INSTRUCTIONS

## INSERTION INSTRUCTIONS

Your TRU Customs have been marked to distinguish between the left and right earpiece. A red dot or 'R' for the right ear, blue dot or 'L' for the left. With the earpiece rotated slightly forward, place the canal portion into your ear canal. Pulling up on the top of your ear with your opposite hand may ease insertion. This straightens your ear canal slightly.

Fully seat the earpiece by rotating it back and in. The use of Oto-Ease may help seat the earpiece into position. A sample pack has been included with your order.

## REMOVAL INSTRUCTIONS

Pull up on the top of the ear slightly to break the seal.

Grasp the earpiece by the removal handle and pull it gently from the ear.

